

Phillips 66

3301 Portage Ave

5296 Breakers Way, Carmel, IN 46033

Facility Name:

Address:

	www.tanksdata.com
\boxtimes	tanksdata@gmail.com
9	(317)-300-6065

Date

4/18/25

Owner:

Address:

City, State, Zip Code: South Bend, IN	City, State,	City, State, Zip Code:									
Facility I.D. #: 18402			Phone #:	Phone #:							
This procedure is to determine whether the automatic tank guage (ATG) is operating properly. See PEI/RP1200 Section 8.2 for the inspection procedure. This procedure is applicable to tank level monitor stems that touch the bottom of the tank when in place.											
Tank Number	1		2		3						
Product Stored	Regular East		Regular West		Premium						
ATG Brand and Model	TLS 350		TLS 350		TLS 350						
1. Tank Volume, gallons	12,000		8,000		6,000						
2. Tank Diameter, inches	96		96		96						
After removing the ATG from the tank, it has been inspected and any damaged or missing parts replaced?	Yes	•	Yes	•	Yes	•			•		
4. Float moves freely on the stem without binding?	Yes	•	Yes	•	Yes	•			•		
5. Fuel float level agrees with the value programmed into the console?	Yes	•	Yes	•	Yes	•].	_		
6. Water float level agrees with the value programmed into the console?	Yes	•	Yes	•	Yes	•			•		
7. Inch level from bottom of stem when 90% alarm is triggered.	81		81		81						
8. Inch level at which the overfill alarm activates corresponds with value programmed in the gauge?	Yes	•	Yes	•	Yes	•			•		
9. Inch level from the bottom when the water float first triggers an alarm.	2		2		2						
10. Inch level at which the water float alarm activates corresponds with value programmed in the gauge?	Yes	•	Yes	•	Yes	•			•		
If any answers in Lines 3, 4, 5, or 6 are "No," the system has failed the test.											
Test Results	Pass	•	Pass	•	Pass	•	. -].	•		
Comment:											
Tester's Name : Josh Rider Tester's Signature :											