

 Midwest Tank Testing AN ENVIRONMENTAL COMPLIANCE COMPANY 316 W. Indiana Ave. Chesterton, IN 46304				AUTOMATIC TANK GAUGE				DATE AND TIME		2/22/23 - 11:00 PM	
				(ATG) FUNCTIONALITY				WEATHER		30 Rainy	
				DATA SHEET				COLLECT/INVOICE		Collected	
								CLIENT E-MAIL			
Testing Company Information											
Test Location Information						Certifications		Name		Midwest Tank Testing	
PC # and WO #						Estabrooks: 82-1906		Address		316 W. Indiana Ave.	
Name and FID #		Phillips 66 - FID 18402				ICC: 10221928		City/State/Zip		Chesterton, IN 46304	
Address		3301 Portage Ave.				Indiana: UC 110386		Phone		800-975-1436	
City/State/Zip		South Bend, IN 46628				CP/STI: 16655		Technician Information			
Contact								Name		Chris Zell	
Phone								Email		support@midwesttanktesting.com	
AUTOMATIC TANK GAUGE (ATG) FUNCTIONALITY TEST											
This procedure is to determine whether the automatic tank gauge (ATG) is operating properly. See PEI/RP1200 Section 8.2 for the inspection procedure. This procedure is applicable to tank level monitor stems that touch the bottom of the tank when in place.											
ATG Brand & Model		TLS 350									
Tank #		1		2		3					
Product Stored		Regular		Mid-grade		Premium					
Tank Volume (gallons)		12k		8k		6k					
Tank Diameter (inches)		96		96		96					
Calculated 90% Level (inches)		91		91		91					
1. After removing the ATG from the tank, it has been inspected and any damaged or missing parts replaced? (Yes/No)		Yes		Yes		Yes					
2. Float moves freely on the stem without binding? (Yes/No)		Yes		Yes		Yes					
3. Fuel float level agrees with the value programmed into the console? (Yes/No)		Yes		Yes		Yes					
4. Water float level agrees with the value programmed into the console? (Yes/No)		Yes		Yes		Yes					
5. Inch level from bottom of stem when 90% alarm is triggered.		91		91		91					
6. Inch level at which the overfill alarm activates corresponds with value programmed in the gauge? (Yes/No)		Yes		Yes		Yes					
7. Inch level from the bottom when the water float first triggers an alarm.		2		2		2					
8. Inch level at which the water float alarm activates corresponds with value programmed in the gauge? (Yes/No)		Yes		Yes		Yes					
If any answers in Lines 1,2,3 or 4 are "No," the system has failed the test.											
Test Results (Pass/Fail)		Pass		Pass		Pass					
Comments											