

### AUTOMATIC TANK GAUGE FUNCTIONALITY TEST

|                        |                        |
|------------------------|------------------------|
| Facility Name:         | Quik Mart Citgo        |
| Address:               | 800 West 61st Ave      |
| City, State, Zip Code: | Merrillville, IN 46410 |
| Facility I.D. #:       | 15886                  |

|                        |                        |
|------------------------|------------------------|
| Owner:                 | PRINCE LLC             |
| Address:               | 800 WEST 61ST AVE      |
| City, State, Zip Code: | Merrillville, IN 46410 |
| Phone #:               |                        |

This procedure is to determine whether the automatic tank gauge (ATG) is operating properly. See PEI/RP1200 Section 8.2 for the inspection procedure. This procedure is applicable to tank level monitor stems that touch the bottom of the tank when in place.

| Tank Number                                                                                               | 1                             | 2                             |                          |                          |                          |
|-----------------------------------------------------------------------------------------------------------|-------------------------------|-------------------------------|--------------------------|--------------------------|--------------------------|
| Product Stored                                                                                            | Regular                       | Premium                       |                          |                          |                          |
| ATG Brand and Model                                                                                       | TLS 300                       | TLS 300                       |                          |                          |                          |
| 1. Tank Volume, gallons                                                                                   | 12,158                        | 4,136                         |                          |                          |                          |
| 2. Tank Diameter, inches                                                                                  | 96                            | 96                            |                          |                          |                          |
| 3. After removing the ATG from the tank, it has been inspected and any damaged or missing parts replaced? | Yes <input type="checkbox"/>  | Yes <input type="checkbox"/>  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 4. Float moves freely on the stem without binding?                                                        | Yes <input type="checkbox"/>  | Yes <input type="checkbox"/>  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 5. Fuel float level agrees with the value programmed into the console?                                    | Yes <input type="checkbox"/>  | Yes <input type="checkbox"/>  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 6. Water float level agrees with the value programmed into the console?                                   | Yes <input type="checkbox"/>  | Yes <input type="checkbox"/>  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 7. Inch level from bottom of stem when 90% alarm is triggered.                                            | 81                            | 81                            |                          |                          |                          |
| 8. Inch level at which the overfill alarm activates corresponds with value programmed in the gauge?       | Yes <input type="checkbox"/>  | Yes <input type="checkbox"/>  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| 9. Inch level from the bottom when the water float first triggers an alarm.                               | 2                             | 2                             |                          |                          |                          |
| 10. Inch level at which the water float alarm activates corresponds with value programmed in the gauge?   | Yes <input type="checkbox"/>  | Yes <input type="checkbox"/>  | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |
| If any answers in Lines 3, 4, 5, or 6 are "No," the system has failed the test.                           |                               |                               |                          |                          |                          |
| Test Results                                                                                              | Pass <input type="checkbox"/> | Pass <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> | <input type="checkbox"/> |

Comment:

Tester's Name : Josh Rider

Tester's Signature :

