

ARCO

5034 E Raymond St

Josh Rider

Tester's Name:

5296 Breakers Way, Carmel, IN 46033

Facility Name:

Address:

| | www.tanksdata.com |
|---|---------------------|
| × | tanksdata@gmail.com |
| 3 | (317)-300-6065 |

Mkr2 Inc.

5034 E Raymond St

Date

01

Tester's Signature :

4/16/25

AUTOMATIC TANK GAUGE FUNCTIONALITY TEST

Owner:

Address:

| City, State, Zip Code: Indianapolis, If | City, State | City, State, Zip Code: Indianapolis, IN 46203 | | | | | | | | | | |
|---|-------------|---|----------|---|---------|---|----|---|--|---|--|--|
| Facility I.D. #: 25298 | | | Phone #: | | | | | | | | | |
| | | | | | | | | | | | | |
| This procedure is to determine whether the automatic tank guage (ATG) is operating properly. See PEI/RP1200 Section 8.2 for the inspection procedure. This procedure is applicable to tank level monitor stems that touch the bottom of the tank when in place. | | | | | | | | | | | | |
| Tank Number | 1 | | 2 | | 3 | | | | | | | |
| Product Stored | Regular | | Premium | | Diesel | | | | | | | |
| ATG Brand and Model | TLS 450 | | TLS 450 | | TLS 450 | | | | | | | |
| 1. Tank Volume, gallons | 12,000 | | 12,000 | | 6,000 | | | | | | | |
| 2. Tank Diameter, inches | 96 | | 96 | | 96 | | | | | | | |
| 3. After removing the ATG from the tank, it has been inspected and any damaged or missing parts replaced? | Yes | • | Yes | • | Yes | • | | • | | • | | |
| 4. Float moves freely on the stem without binding? | Yes | • | Yes | • | Yes | • | | • | | • | | |
| 5. Fuel float level agrees with the value programmed into the console? | Yes | • | Yes | • | Yes | • | | • | | • | | |
| 6. Water float level agrees with the value programmed into the console? | Yes | • | Yes | ~ | Yes | • | | • | | • | | |
| 7. Inch level from bottom of stem when 90% alarm is triggered. | I Q1 | | 81 | | 81 | | | | | | | |
| 8. Inch level at which the overfill alarm activates corresponds with value programmed in the gauge? | Yes | • | Yes | • | Yes | • | | • | | • | | |
| 9. Inch level from the bottom when the water float first triggers an alarm. | 2 | | 2 | | 2 | | | | | | | |
| 10. Inch level at which the water float alarm activates corresponds with value programmed in the gauge? | Yes | • | Yes | • | Yes | • | | • | | • | | |
| If any answers in Lines 3, 4, 5, or 6 are "No," the system has failed the test. | | | | | | | | | | | | |
| Test Results | Pass | • | Pass | • | Pass | • |]. | • | | • | | |
| Comment: | | | | | | | | | | | | |