

5296 Breakers Way, Carmel, IN 46033

| | www.tanksdata.com |
|---------|---------------------|
| oxtimes | tanksdata@gmail.com |
| 0 | (317)-300-6065 |

Date

7/8/25

AUTOMATIC TANK GAUGE FUNCTIONALITY TEST

| Facility Name: | Handy Spot Marathon |
|------------------------|-------------------------|
| Address: | 2101 E Michigan Blvd |
| City, State, Zip Code: | Michigan City, IN 46360 |
| Facility I.D. #: | 2986 |

Owner: NPR Bros Inc

Address: 2101 E Michigan Blvd

City, State, Zip Code: Michigan City, IN 46360

Phone #:

| This procedure is to determine whether the automatic tank guage (ATG) is operating properly. See PEI/RP1200 Section 8.2 for the inspection procedure. This procedure is applicable to tank level monitor stems that touch the bottom of the tank when in place. | | | | | | | | | | | |
|---|---------|---|---------|---|---------|---|---------|---|---|--|--|
| Tank Number | 1 | | 2 | | 3 | | 4 | | | | |
| Product Stored | Premium | | E-85 | | Diesel | | Regular | | | | |
| ATG Brand and Model | TLS 350 | | TLS 350 | | TLS 350 | | TLS 350 | | | | |
| 1. Tank Volume, gallons | 4,435 | | 3,000 | | 4,474 | | 22,229 | | | | |
| 2. Tank Diameter, inches | 120 | | 120 | | 120 | | 120 | | | | |
| After removing the ATG from the tank, it has been inspected and any damaged or missing parts replaced? | Yes | • | | • | Yes | • | Yes | • | • | | |
| 4. Float moves freely on the stem without binding? | Yes | • | | • | Yes | • | Yes | • | | | |
| 5. Fuel float level agrees with the value programmed into the console? | Yes | • | | • | Yes | • | Yes | • | • | | |
| Water float level agrees with the value programmed into the console? | Yes | • | | • | Yes | • | Yes | • | | | |
| 7. Inch level from bottom of stem when 90% alarm is triggered. | 108 | | | | 108 | | 108 | | | | |
| Inch level at which the overfill alarm activates corresponds with value programmed in the gauge? | Yes | • | | • | Yes | • | Yes | • | | | |
| 9. Inch level from the bottom when the water float first triggers an alarm. | 2 | | | | 2 | 2 | | 2 | | | |
| 10. Inch level at which the water float alarm activates corresponds with value programmed in the gauge? | Yes | • | | • | Yes | • | Yes | • | • | | |
| If any answers in Lines 3, 4, 5, or 6 are "No," the system has failed the test. | | | | | | | | | | | |
| Test Results | Pass | • | | • | Pass | • | Pass | • | | | |

Comment: DSL probe wire in rough shape but is properly reading currently. E-85 was not tested bc it's not working properly and requires maintenance

Tester's Signature :